

I have a code E2 or E3 on my display

A. For both codes, check the connections on your device:


1. Unplug the power cable.



2. Check the cable connections behind the control console.




3. Unscrew the stem tube and lift it up.



4. Check the visual condition of the cables for cuts, rubbing, or other damage.



5. Unplug the connectors to check the condition of the pins, and reposition them if they are bent or twisted.



6. Reconnect the cables.

7. Put the stem tube back in place.

8. Tighten the screws.



9. Plug in the power cable.



10. Test.

B. If code E2 continues:

- Unplug the power cable from the device (leave the other end plugged into the power socket).

- Wait 5 seconds.

- Plug the power cable back into the device.

- Repeat up to 5 times.